18*10W USER MANUAL

一：Display Operation

 Press"MENU" to main menu，press "UP" or "DOWN" to choose sub menu，press"ENTER"comfirm and save.

MENU 菜单	UP 上	DOWN 下	ENTER 确定

d001	➡	d512	➡	4CH mode

A001	➡	A512	➡	8CH mode

FF01	➡	FF99	➡	RGB color gradual changing

CC01	➡	CC99	➡	RGB color jump changing

r001	➡	r255	➡	Dimmer adjustment by hand
		G255	➡	Dimmer adjustment by hand
		b255	➡	Dimmera djustment by hand
		w255	➡	Dimmer adjustment by hand

dEoo	➡	dEoo	➡	Demo mode

SoUd	➡	SoUd	➡	Sound mode

SLAv	➡	SLAv	➡	Master/slave mode

二：Channel

4CH		
CH	ADDRESS	FUCTION
CH1	0	red off
	1-255	gradual change (from dark to bright)
CH2	0	green off
	1-255	gradual change (from dark to bright)
CH3	0	blue off
	1-255	gradual change (from dark to bright)
CH4	0	white off
	1-255	gradual change (from dark to bright)

8 CH		
CH	ADDRESS	FUCTION
CH1	0-255	Total dimmer
CH2	0	red off
	1-255	gradual change (dark to bright)
CH3	0	green off
	1-255	gradual change (dark to bright)
	0	blue off

CH4	1-255	gradual change (dark to bright)
CH5	0	white off
	1-255	gradual change (dark to bright)
CH6	0-255	Strobe(slow to fast)
CH7	0-255	Speed(slow to fast)
CH8	0-50	OPEN CH1-CH6
	51-100	program-color selection
	101-150	program-gradual change
	151-200	program-pluse change
	201-250	program-jump change
	251-255	open sound control

三：Master/slave set

2pcs or more same lights connect by 3pin xlr，set anyone to demo mode
/jamp/gradual change.，the others set to receive address "SLAV" or "d001"

四：Product Features

■ CH：4/8 DMX512 channels

■ Master/slave, auto-running

■ strobe，color selection, dimmer , color change。

■ 0-100%liner dimmer